



## 17. Three-way Switches & Light Fixture (Fixture Between Switches)

This layout for three-way switches lets you control a light fixture from two locations. Each switch has one COMMON screw terminal and two TRAVELER screws. Circuit wires attached to the TRAVELER screws run between the two switches, and hot wires attached to the COMMON screws bring current from the power source and carry it to the light fixture. Requires two-wire and three-wire cables.



I want to replace this switch with an always-on outlet.

I have the option of replacing the single-gang box with a double-gang box so I could add the outlet next to the switch if that is more practical.